



TURN THE DISPLAY ON


Push the right button under the screen.

PLUG YOUR PC IN

Plug the HDMI cable from the desk in your personal PC.


Press **1** and select IMPORTA → PC → HDMI on the upper part of the screen.

To enable the touchscreen, plug the USB cable from the desk in your PC.



USING THE SCREEN AS AN INTERACTIVE BOARD (WITH PENCIL)

SCREEN MENU



Drawing:

Use the pen to draw freely on the screen.

Thin trait → “tipo penna”

Thick trait → “tipo evidenziatore”

Changing thickness and colour:

Hold the tip of the pen on the screen to select the properties.

Erasing:

Use your finger or your hand to erase.

Selection	Action
1	Select to open the IMPORTA/ESPORTA menu - IMPORTA : Import the screen from a PC or a mobile device, or import data from a USB device - ESPORTA : export data to selected formats
2 Modalità penna	Press to select the PEN or BRUSH mode
3 Tavolozza	Press to open the colour palette, to set colour and pen/marker thickness
4 Strumenti matematici	Open the math tools to draw geometric shapes of measure distances
5 Selezione	Select and modify/copy/email/print/search elements
6 Annulla Ripeti	Undo / repeat the action (up to twenty actions can be undone)
7 Pagg	Add/delete a page or scroll the current document
8 Nota attivata/disattivata	Add a layer. Layers can be superimposed and saved as a new image
9 Miniboard	Activate the Miniboard. The Miniboard is an independent portion of screen
10 Cerca	Search the Internet
11 Menu	Show menu
12	Close the document to open a new one